



IW-25 SURFACE MOUNTING BOX INSTRUCTIONS



Attach the surface mounting box to the wall by locating studs or wall anchors making sure the box is level and secure. Next, lean the top of the IW-25 toward you and insert the bottom of the unit into the box.

Pull the bottom front of the IW-25 toward the front of the box while simultaneously pushing the top rear of the cabinet into the box as demonstrated in the two photos above.



Gently lift the IW-25 off the bottom of the surface mounting box and align the cabinet flanges with the pre-drilled holes



Using sheet metal screws secure the IW-25 to the surface mounting box.